



1.) Add (2) metal clips to motor outlet collar*. Make sure the clips face each other in the same orientation.

**note: there is no need to replace the metal clips if they are already attached to the motor outlet collar.*



2.) Peel protective film from butterfly damper.



3.) Insert narrow end of rod into hole on metal clip.



4.) Insert end of rod with loop into the slot on second metal clip.